

Twos R Us

Trunk Spring Helper

Installation Instructions

Thank you for your purchase of the Twos R Us MR2 trunk spring helper. This gas charged strut will assist aging trunk springs in holding open the rear deck on the MKI MR2.

Tools required:

Straight blade screwdriver

Socket

12mm socket

½" open end wrench

½" socket

Drill

1. Locate the wiring harness holder that attaches to the upper arm on the trunk spring and remove the plastic tab from the hole in the spring arm using the straight blade screwdriver. You may wish to re-attach this harness to the spring arm using electrical tape or zip ties.
2. Using the supplied drill bit, enlarge the hole in the upper spring arm. Insert the threaded ball end through this hole with the ball facing the driver's side of the car and attach with supplied lock nut.
3. Locate the two 12mm bolts holding the lower arm of the spring in the trunk and remove the rear-most bolt. Insert this bolt through the large, center hole in the supplied bracket and replace bolt. The ball mount on the bracket should face down when installed.
4. Snap the plastic strut ends onto the installed ball mounts with the body of the gas strut facing up and the shaft facing down.
5. Clean up your work area and enjoy your revived trunk spring!

If you should ever need to remove the strut, insert a small straight blade screwdriver between the metal clip and the plastic on the rod ends and pry the clip up to release the ball from the end.

